
List of figures

Figure 1	
Apparatus designations	2
Figure 2	
Zone cabling and conduit assignment	4
Figure 3	
NE-500/2500-type telephones—limits and cabling	5
Figure 4	
SL-1 telephones—limits and cabling	9
Figure 5	
QCW-type attendant console—limits and cabling	10
Figure 6	
Typical QCW-type attendant console faceplate layout	14
Figure 7	
M1250 assembly drawing (exploded view)	17
Figure 8	
M2250 assembly drawing (exploded view)	18
Figure 9	
Typical key designations for the QCW attendant console	22
Figure 10	
M1250/M2250 key designations in Shift mode (QMT2 not enabled) .	23
Figure 11	
M1250/M2250 key designations in Shift mode (QMT2 enabled)	24
Figure 12	
M1250/M2250 key designations in Unshift mode (QMT2 enabled) . .	25

Figure 13	
M1250/M2250 designations in Unshift mode (QMT2 not enabled) . .	26
Figure 14	
QCW and M1250 attendant console cross-connections	29
Figure 15	
M2250 attendant console cross-connections	33
Figure 16	
SL-1 telephone faceplate	41
Figure 17	
M2000 digital telephone connections	43
Figure 18	
Meridian Modular Telephone connections	47
Figure 19	
Meridian Modular Telephone cross-connections	48
Figure 20	
M2317 digital telephone cross-connections	52
Figure 21	
M3000 Touchphone cross-connections	59
Figure 22	
SL-1 and M1109 telephone connections	65
Figure 23	
NE-500/2500-type telephone cross-connections for PE modules . . .	69
Figure 24	
SL-1 telephone cross-connections	74
Figure 25	
Meridian Modular Telephone cross-connections	75
Figure 26	
QMT1 and QMT2 add-on module faceplate	81
Figure 27	
Add-on module connection to the SL-1 telephone	83
Figure 28	
Add-on module connection to an attendant console	84

Figure 29	
QMT3 Lamp Field Array connections to the attendant console	93
Figure 30	
QMT3 Lamp Field Array connections to the SL-1 telephone	94
Figure 31	
The Busy Lamp Field/Console Graphics Module on the M1250/M2250 attendant console	96
Figure 32	
Volume slider position	97
Figure 33	
Removing the fastening screws	98
Figure 34	
Removing the top cover	99
Figure 35	
Attendant console knockout section	100
Figure 36	
Connecting the BLF/CGM to the attendant console	101
Figure 37	
Support spacer	102
Figure 38	
Positioning the top cover and the BLF/CGM	103
Figure 39	
Attaching the top cover to the attendant console base and BLF/CGM	104
Figure 40	
Identifying the correct grid positions on the main PCB and attaching the ASM	109
Figure 41	
The QMT4 A/B handset module attached and connected to the attendant console	113
Figure 42	
QMT4A, B, and C handset module	118
Figure 43	
QMT15 amplified handset module	119

Figure 44	
Current limiting kit connections	120
Figure 45	
Light Probe PCB connections to an attendant console and SL-1 telephone	137
Figure 46	
QUT1 power unit faceplate	143
Figure 47	
QUT1 power unit connection	144
Figure 48	
M2000/M2317 data terminal and Data Option power supply connection	150
Figure 49	
M3000 data terminal and DTE/computer terminal connection	152
Figure 50	
Exploded view of the M2616/M2016S/M2216ACD telephone	155
Figure 51	
Installing the MCA	168
Figure 52	
M2006/2008 telephone and option boards	172
Figure 53	
M2616/M2216ACD telephone and option boards	173
Figure 54	
Configuration of a local plug-in transformer	176
Figure 55	
Closet power supply configuration	177
Figure 56	
Ribbon cable placement	180
Figure 57	
Display cable routing	183
Figure 58	
Display cable routing	187

Figure 59	
Positioning the display module	189
Figure 60	
Connecting the Display Module Ribbon Cable, NTZK model	190
Figure 61	
Connecting the Display Module Ribbon Cable, NT2K model	191
Figure 62	
Connecting the cable to the display board	194
Figure 63	
External Alerter connecting block configuration	200
Figure 64	
Key Expansion Module connections (bottom view)	203
Figure 65	
Flowchart for troubleshooting MCA	209

